

Blue-ray, DVD- und Videoabspielgeräte

| Bild | Daten |
|---|--|
|  | <p>27 95095-01 BLUE-RAY 3D DISC DVD-Player PHILIPS</p> |
|  | <p>27 95097-01 BLUE-RAY 3D DISC DVD-Player SONY</p> |
|  | <p>27 95108-01 DVD/VHS-Player PANASONIC mit Kopierfunktion</p> |
|  | <p>27 95105-01 DVD/VHS-Player PHILIPS DVP 3350 V</p> |
|  | <p>27 95103-01 DVD-Player PANASONIC S47</p> |
|  | <p>27 95102-01 DVD-Player SEG</p> |

| | |
|---|---|
|  | 27 95101-01 DVD-Player SABA |
|  | 27 95100-01 DVD-Player TOSHIBA |
|  | 27 95110-01 VHS-Videorecorder JVR |
|  | 27 95113-01 Mini-DV/S-VHS Kopiergerät JVC |
|  | 27 95109-01 VHS-Videorecorder PANASONIC |
|  | 27 95114-01 VHS-Videorecorder PANASONIC NV |